



1955 BODY BOLT KIT

400A

<u>Location</u>	<u>Attach With</u>
1	2 3/8 dia studs short end down 2 3/8 lock nuts 2 3/8 flat washers
2	2 7/16 dia studs 2 7/16 hex nuts 2 7/16 lock washers 2 7/16 flat washers
3,5,7	6 3/8 x 2 bolts 6 stamped flat washers 6 caged nuts (not included)
4,6	4 3/8 x 2 3/4 bolts 4 stamped flat washers 4 caged nuts (not included)
8,9	4 3/8 x 2 bolts 4 stamped flat washers

